




CABINET PARTS

For Models: LER7646EQ1, LER7646EZ1
(Designer White) (Designer Almond)

ELECTRIC DRYER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS


For Models: LER7646EQ1, LER7646EZ1
(Designer White) (Designer Almond)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
2	343641	Screw, 10-16 x 1/2	18		Cabinet (Includes Illus. No's. 5, 7, 15, 16, 41 & 57)	38	3406129	Seal & Bearing Assembly
3	693995	Screw, Hex Washer Head		3399585	White	39	279393	Terminal Block Kit (For Terminal Block)
4	238614	Bumper		3399586	Almond	40	3393008	Screw, 10-16 x 1/2
5	3396795	Cover, Block	19	98234	Clip, Ground	41	3397659	Block, Terminal
6	342043	Screw, 10-32 x 1/2	20	690363	Lock, Front Top (2)	51	238088	Hinge, Top (2)
7	3396805	Panel, Rear	21		Panel, Front	53	691366	Idler & Pulley Assembly
10	3406101	Door Switch Assembly		695620	White	56	660996	Belt, Drive
11	697773	Screw, 6-20 x 7/8		695621	Almond	57	348780	Base, Motor
13	3357011	Screw, 10-16 x 1/2	23	685203	Clip, Felt Pad (3)	58	3400500	Bolt, 5/16-18 x 3/4
14	692495	Spring, Door (2)	24	3398175	Catch, Door Assembly	59	3401143	Pulley, 60 Hz.
15	3394083	Clip, Front Panel (2)	26	337189	Clip, Hinge (2)	62	3395652	Motor Assembly 60 Hz.
16	3392100	Foot, Dryer	27	694091	Screw (6)	63	660658	Clamp, Motor
	279810	Foot - Optional (Extended Length Package Of 2) (Not Included)	28	692498	Hinge, R.H.	64	3404162	Clamp, Motor (W/Shield)
				692501	Hinge, L.H.	67	3390731	Seal, Door
17	279318	Terminal, Tinned & Brass (3) (Includes Illus. 39)	33	696144	Strike, Door	87	697776	Screw, 10-32 x 1/2 (External Ground)
			35	695737	Door, Rear			
			36		Door, Front			
				3393549	White			
				3393550	Almond			
			37		Handle, Door			
				690270	White			
				690271	Almond			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS

For Models: LER7646EQ1, LER7646EZ1
(Designer White) (Designer Almond)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS

For Models: LER7646EQ1, LER7646EZ1
(Designer White) (Designer Almond)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	3397545	Panel, Rear Console	13	688983	Screw, 8–15 x 5/8	32	3396029	Wire–Jumper Assembly (Temperature)
3	694419	Buzzer, Mini	15	3354285	Switch, Finish Guard	39	3398095	Relay, Push–To–Start
4		Cap, End (L.H.)	16		Top	40	3401144	Connector (PTS Relay)
	3358528	White		3396022	White	41	3397269	Connector (Timer)
	3358529	Almond		3396023	Almond	48		Timer Knob Assembly
5	3397695	Wire, Jumper (Guard/On–Off)	17	3401684	Wire, Jumper (Black)		3396146	White
6	388326	Screw, Console	18	3399639	Switch, Temperature		3396149	Almond
7	693995	Screw, Hex Head	19	688805	Clip	49	3950759	White Knob, Control (3)
8		Cap, End (R.H.)	20	3347243	Connector 6–Circuit		3950760	Almond
	3358513	White	21	3406701	Timer, 60 Hz.	50	353425	Connector (Door Switch)
	3358514	Almond	22	357572	Clip, Grounding	53	3396293	Bracket, Control Panel, Control
9	3395683	Housing, Connector (Motor)	23	3394427	Clip, Harness	54	3399053	White
10	349639	Screen, Lint	24	94614	Terminal		3399054	Almond
11		Cover, Lint Screen	25	3401075	Resistor Assembly	72	690853	Wire, Ground
	688150	White	29	3390646	Screw, 8–18 x 5/16			
	689310	Almond	30	357213	Nut, Push–In (2)			
12	339229	Hinge, R.H.	31	3406616	Harness, Wiring			
	339230	Hinge, L.H.						


LITERATURE AND OPTIONAL PARTS

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
<u>LITERATURE PARTS</u>			<u>OPTIONAL PARTS NOT INCLUDED</u>					
LIT3397618		Instructions, Installation	<u>PAINT, TOUCH–UP (1/2oz.)</u>			<u>PAINT, BULK (1 qt.)</u>		
LIT3406071		Use & Care Guide		72017	White		799344	White (Uncut)
LIT3406692		Label, Wiring Diagram		72107	Almond		978883	Almond (Uncut)
LIT3397286		Label, Warning	<u>PAINT, PRESSURIZED SPRAY (13 oz.)</u>			<u>Following May Be Purchased</u>		
				350930	White	<u>DO–IT–YOURSELF REPAIR MANUALS</u>		
				350956	Almond		LIT677818	Dryer
				350938	Primer, Gray			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Models: LER7646EQ1, LER7646EZ1
(Designer White) (Designer Almond)



Illus. No.	Part No.	DESCRIPTION
1	348368	Lint Chute Assembly
2	3400800	Screw, 8-18 x 3/4"
3	3388703	Washer-Support
4	347139	Seal, Lint Chute
5	90767	Screw, 8A x 3/8
6	696302	Shield, Exhaust
7	3392519	Thermal Fuse
8	3387134	Thermostat, Internal-Bias
9	3399848	Thermal Cut-Off (Hi-Limit Thermostat Illus. No.15 Included)
10	694089	Wheel, Blower (Includes Illus. No. 22)

Illus. No.	Part No.	DESCRIPTION
11	3405016	Housing, Blower
12	3398161	Clip
13	343641	Screw, 10-16 x 1/2
14	3397566	Box, Heater
15	3399693	Thermostat, 250°F (121.1°C)
16	3404232	Bracket, Drum Light
17	3403585	Element, Heater
18	3403634	Socket Assembly
19	279457	Wire Kit, Terminal (For Heater Element Wiring Harness Repair)
20	3406124	Bulb
21	3402729	Lens, Drum Light
22	3394196	Seal, Blower

Illus. No.	Part No.	DESCRIPTION
23	3357011	Screw, 10-12 x 1/2
41	690997	Ring, Tri
42	3399506	Shaft, L.H.
43	3399507	Shaft, R.H.
44	3397588	Roller, Support
46	348197	Washer, Support
47	3359452	Nut, 3/8-16
48	3403493	Bulkhead
62	692526	Ring, Bearing
63	97787	Screw, 11-16 x 7/8
66	3406130	Seal, Rear Drum
67	695587	Drum Assembly
68	692490	Baffle, Drum (2)
69	3394133	Bracket, Support
70	90296	Clip
71	3403636	Baffle, Drum (1)
73	339956	Seal

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST